

INSTALLATION MANUAL



EVO J-BOX


SAVING TIME, ENERGY & MONEY



evoheat.com.au 1300 859 933



The Evo J-Box allows your heat pump to turn the main water pump on outside of your filtration times, saving you time, energy & money!





Simple to install

Easy to use

Save on running costs


Set and forget

No water balance issues

Only require one water pump

EASY INSTALLATION – ELECTRICAL CONNECTION

- The heat pump, J-Box & water pump are all on the same circuit
- The electrical connection of the J-Box is separate to the electric connection of the heat pump
- The J-Box is supplied power via the chlorinator, whereas the heat pump requires an independent power supply
- Refer to the heat pump owner's manual for power supply requirements and details on electrical connection.



CONNECTING TO THE HEAT PUMP TERMINAL BLOCK

- Connect J-Box Active to Heat Pump Active (Brown Cable)
- Connect J-Box Neutral to Heat Pump Neutral (Blue Cable)
- Connect J-Box Earth to Heat Pump Earth (Green/Yellow Cable)
- Connect J-Box Active to Heat Pump Terminal 1 or Water Pump L

 depending on model (White Cable)



